

Titration Kit

Product-specific multiplication factors – Americas: US, CA, MX

Note: Factor based on Blaser titration kit method. Not valid for other titration methods.

Product	Art. no.	Multiplication Factor
Blasocut 2000 Universal	00870-80	13.43
Blasocut 2000 CF	00875-80	12.39
Blasocut 2000 CF SW	00875-21	9.54
Blasocut 4000 Strong	00872-80	9.12
Blasocut BC 20	01200-05	6.39
Blasocut BC 20 SW <i>Mexico</i>	01200-67	6.81
Blasocut BC 20 SW	01200-69	5.11
Blasocut BC 25 MD	01250-23	6.63
Blasocut BC 25 SW UHV	01250-68	6.08
Blasocut BC 35 NF	01351-02	10.11
Blasocut BC 35 SW	01350-21	5.72
Blasocut BC 37 MG	01370-02	12.07
Blasocut BC 40 NF	01401-04	10.78
Blasocut BC 40 SW	01400-61	5.63
Blasocut BC 935	01935-02	4.88
Blasocut BC 935 SW	01935-65	4.52
Blasocut BC 940	01940-03	4.59
Blasocut BC 940 SW	01940-67	4.52
Vasco 3000 CI	02830-41	2.29
Vasco 5000	02850-05	10.16
Vasco 5060	02856-02	9.32
Vasco 6000	02860-01	2.06
Vasco 7000	02870-43	2.99
B-Cool 655 <i>Canada</i>	11655-04	2.41
B-Cool 755	11755-43	3.43
B-Cool 9665	19665-45	1.82
B-Cool GR 620	11620-02	1.87
B-Cool MC 600	11600-41	2.91
B-Cool MC 610 <i>Mexico</i>	11610-01	2.75
Synergy 905	11905-05	2.55
Synergy 915 <i>Mexico</i>	11915-03	1.87
Grindex 10 CO	01100-05	1.09
Grindex 10	01101-08	0.98

Example of concentration by titration:

Volume of acid in ml (milliliters) used to change color x factor = concentration % by volume.

BC 20 SW art. 01200-69: 2.1 ml acid x 5.11 = 10.7% concentration